

10b

Car Parts



Spark Plug



Brake Pad



Shock Absorber



Airbag



Remote control / Key



Car Engine



Turbocharger



Pistons



Radiator



Battery



Speedometer



Steering Wheel



Car Seat



Air Conditioning



Seat Belts



Gear Stick



Windscreen Wiper



Oil



Clutch Brake Accelerator

Verbs

FIX

REPAIR

CHECK

TEST

FUNCTION

WORK

REPLACE

CHANGE

TIGHTEN

LOOSEN




Wheels



Tyres



Jack



Garage / Workshop



Tow truck

Questions

How does the air conditioning work?

How do I move the seats forward?

Where is the switch for the headlights?

How do I turn the fog lights on?

The car service

The tyres are very worn.

We need to change all the brake pads.

We need to check the oil.

We will change the battery for you.

We have to replace the radiator.